


25163

AIRPORT DIAGRAM

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

AL-50 (FAA)

BIRMINGHAM, ALABAMA



SE-4, 25 DEC 2025 to 22 JAN 2026

AIRPORT DIAGRAM

25163

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)


BIRMINGHAM, ALABAMA

AIRPORT DIAGRAM

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

AL-50 (FAA)

BIRMINGHAM, ALABAMA



CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

AIRPORT DIAGRAM

BIRMINGHAM, ALABAMA

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

SE-4, 22 JAN 2026 to 19 FEB 2026