OLD


26134

# AIRPORT DIAGRAM

## BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

AL-50 (FAA)

BIRMINGHAM, ALABAMA




SE-4, 01 OCT 2026 to 29 OCT 2026

SE-4, 01 OCT 2026 to 29 OCT 2026


# AIRPORT DIAGRAM

26134

BIRMINGHAM, ALABAMA

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

NEW


26302

# AIRPORT DIAGRAM

## BIRMINGHAM-SHUTTLESWORTH INTL (BHM)

AL-50 (FAA)

BIRMINGHAM, ALABAMA




SAID in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.

SE-4, 29 OCT 2026 to 26 NOV 2026

SE-4, 29 OCT 2026 to 26 NOV 2026


AIRPORT DIAGRAM

26302

BIRMINGHAM, ALABAMA

BIRMINGHAM-SHUTTLESWORTH INTL (BHM)